







































Adjust vertical speed (reduce rate of descent) Adjust vertical speed (multi-threat advisory) The Safety and Failure of Avionics Systems: Example of ACAS/TCAS

20

Rechnernetze und Verteilte Systeme May-Dec 2004































